

# UNDERGROUND HAZARDS AND LOCATES

Date Revised:	August 2024	Overall Task Risk Rating:	Before Controls	В	After Controls	С
Description:	All utilities must be located and marked. Underground utilities range from hydro, communication cables, gas, fibre optic lines, existing water mains, TV cables, storm drains, sanitary sewers, etc.					
Location(s):	Construction Projects					
Associated Documents: Trenching and Excavating WTS, Housekeeping WTS, Equipment and Machinery Operation WTS, Hazardous Energy Control WTS						ду

## **RED FLAGS (HOLD WORK UNTIL CORRECTED):**

Note:

- Do not commence work if you haven't got the locates done for the underground utilities in the area
- Always remember to contact "ONTARIO ONE CALL" before you dig
- If you find an unidentified utility, STOP and contact the utility owner immediately

PERSONAL PROTECTIVE EQUIPMENT (CSA APPROVED)									
						B	×		
Head Protection	Foot Protection	High-Vis Protection	Hearing Protection	Hand Protection	Eye Protection	Respiratory Protection	Skin Protection	Face Protection	Fall Protection
Note: - Additional PPE such as eye protection (i.e. safety glasses), hand protection (i.e. gloves) and respiratory protection (i.e. a full face respirator) may be required depending on the task and surrounding environment									

# SAFE WORK PRACTICES (SWP)

General Locates Practices:

- All underground utilities that may be encountered during the excavation must be located and marked prior to breaking ground
- · Always contact "ONTARIO ONE CALL" for locating any underground utilities that may be on a project for locate request services
- Where underground utility cannot be located contact utility owner to assist with manual locate
- Ensure supervisors and operators have locates available if equipment is to be used around underground electrical or energy hazards
- Ensure workers are provided copies of utility locates (as necessary) and that the content/specifications set out therein, are current and communicated to them
- If you find an error or an unidentified utility, STOP and contact the utility owner immediately
- If the utility may pose a hazard, the service shall be locked-out / tagged-out (LO / TO)
- While the excavation is open, underground utilities shall be protected, supported, or removed as necessary to protect employees Digging Techniques:
- Do not use mechanical excavation within locate boundary limits
- Use non-intrusive methods of excavating material within restricted areas around utilities
- Uncover utilities using hand digging methods
- To ensure that you've exposed the correct utility, you may need assistance (hydro vac, subsurface imaging, radar (GPR), x-ray, etc.)
- Ensure excavation does not occur outside of the area where locates were obtained, without obtaining further locates



Utility Locate Markings:

- Ensure locates are up to date, and clearly marked onsite
- To help the locator on site, the excavator is to white line the dig area
- Ensure utility owner indicates, using labelled stakes / flags / paint, the centre line of underground utilities in the vicinity of the proposed excavation
- Ensure a diagram of the locate information is provided
- A colour code for marking buried utilities is used by contractors, locators, and utility owners throughout North America
- Re-conduct locates if markings not identifiable
- If locates are expired a new set of locates must be obtained
- Locate documents must be available onsite
- Do not remove or deface conducted utility locates

### Inspections:

- Keep track of utility locates conducted onsite
- Inspect uncovered utilities for damage, and to ensure they are supported appropriately
- All workers must consult the utility locates report/diagram, prior to commencing excavation (and related) activities Training:
- Employee Orientations (including roles, responsibilities, applicable workplace task standards, WHMIS, etc.)
- Ensure utility locates are conducted by competent workers
- Ensure workers who are provided copies of utility locates, are competent and understand the content and specifications outlined
- Only trained, authorized personnel are allowed to operate machinery or equipment
- Only operate machinery and equipment that you are authorized and trained to use

Personal Protective Equipment:

- Workers on construction projects must wear, at a minimum, head, foot and high visibility protection. Eye protection when necessary
- Eye protection is required when completing tasks that may cause debris / objects to dislodge or become airborne

JOB HAZARD AND RISK A		RISK RATING SYSTEM C Low risk of injury or equipment / property da	
TASK HAZARDS	RATING BEFORE CONTROLS	TASK CONTROLS	RATING AFTER CONTROLS
<ul> <li>Lack of Documentation, Locates</li> </ul>	В	<ul> <li>Before you dig, mark the proposed excavation area and contact "ONTARIO ONE CALL" to obtain locates for all underground utilities</li> <li>Keep all documentation on the job-site showing proof that the locates were made</li> </ul>	С
<ul> <li>Lack of Site Planning and Storage Knowledge</li> </ul>	В	<ul> <li>Ensure excavation does not occur outside of the area where locates were obtained, without obtaining further locates</li> </ul>	С
<ul> <li>Utilities Not Located</li> </ul>	В	<ul> <li>Where underground utility cannot be located contact utility owner to assist with manual locate</li> <li>Confirm location of all utilities within excavation area by hand digging</li> </ul>	С
<ul> <li>Located Utilities Not Marked</li> </ul>	В	<ul> <li>Ensure locates are up to date, and clearly marked onsite</li> <li>Ensure utility owner indicates, the centre line of underground utilities in the vicinity of the proposed excavation</li> <li>Ensure a diagram of the locate information is provided</li> <li>Re-conduct locates if markings not identifiable</li> </ul>	С
Unstable or Live Utilities	В	<ul> <li>If the utility may pose a hazard, the service shall be LO / TO</li> <li>While the excavation is open, underground utilities shall be protected, supported, or removed as necessary</li> </ul>	С

Gazzola Paving Limited

Reviewed Date: March 18, 2025

Utility or Product	Paint Colour		
Electric - Powerlines; Cables; Conduit and lighting cables	Red		
Gas; Oil; Steam; Petroleum; Compressed air and gases (e.g., propane); Other hazardous liquid or gaseous materials except water	Yellow		
Communications - CATV; Alarms; Signal lines; Cables and conduit (phone and fibre optics)	Orange		
Water	Blue		
Sewers; Drain lines	Green		
Reclaimed/treated water; Irrigation and slurry lines	Purple		
Temporary survey marks	Pink		
Proposed evacuations	White		



# UNDERGROUND HAZARDS AND LOCATES

Mechanical Excavation in     Close Proximity to Utilities	В	<ul> <li>Do not use mechanical excavation in locate boundary limits</li> <li>Use non-intrusive methods of excavating material within 1 metre of centre line of marked utilities (i.e. hand digging or hydro vactor)</li> <li>Dig test holes to find the line and depth of the utility</li> </ul>	C	
Expired Utility Locates	С	<ul> <li>Each utility can have different expiration periods (~30 days)</li> <li>Get new locates done before the old ones expire</li> <li>Request locates at least 5 to 10 days in advance of expiry</li> </ul>	С	
Lack of Communication	С	<ul> <li>Established safe working zones while digging in proximity to underground utilities</li> </ul>	С	
<ul> <li>Lack of Training</li> </ul>	С	<ul> <li>Excavation equipment is to be operated and maintained by competent trained and authorized personnel</li> <li>Ensure utility leasters are conducted by competent workers</li> </ul>		С
		<ul> <li>Ensure utility locates are conducted by competent workers</li> <li>Ensure workers who are provided copies of utility locates, are competent and understand the content and specifications outlined</li> </ul>		

## SAFE JOB PROCEDURES (SJP)

## Pre-Task Commencement:

- 1. Gather and wear the required PPE for the task on construction sites, all must wear head, foot and high visibility protection. Eye protection when necessary
- 2. Ensure the site-specific workplace violence assessment is complete
- 3. Complete the Daily GAZZ Card and review with all workers the shift's tasks with any associated hazards and control strategies
- 4. Ensure all workers understand the GAZZ Card contents, and sign off in acknowledgement
- 5. Ensure controls are in place prior to commencing work so risks are mitigated / eliminated
- 6. Determine what equipment / machinery / tools and material, are required for the completion of the task
- 7. Inspect all equipment / machinery / tools prior to use and document the inspections on appropriate forms when required
- 8. Ensure preventative maintenance activities have been completed where required, prior to using equipment / machinery / tools
- 9. If equipment / machinery / tools are observed to be damaged, remove it from use and notify the Foreman / Superintendent
- 10. Install fencing and hoarding where needed
- 11. Call "ONTARIO ONE CALL" for locating services of all buried utilities to request that they locate and mark the utilities and provide a diagram describing the locate information
- 12. The excavation area should be outlined by a white line when possible

## During Task:

- 1. Review locate and ensure compliance to utility location and active work
- 2. Locate centre line of utility
- 3. Ensure the operator has a copy of the locates
- 4. Determine excavating procedures
- 5. Communicate with near-by workers to inform them that work is commencing
- 6. Support utilities to prevent failure or breakage

#### Note - If un-located utilities or damaged utilities are discovered:

- 1. Stop all related work activities
- 2. Contact the utility owner
- 3. Verify the damaged area by taking pictures, notes (i.e. elevations, etc.) and complete an incident report

### Task Completion:

- 1. Ensure all equipment / machinery / tools are maintained and stored appropriately in the designated locations
- 2. Implement any housekeeping or maintenance as required